




PSP5 Universal Phantom Power Supply For Condenser Microphones, 48v

Thank you for purchasing this Rockville PSP5 48v Universal Phantom Power Supply for condenser microphones. Please read this guide carefully for proper use of your Rockville PSP5. Should you need assistance, please call our technical help line at 1-646-758-0144, 24 hours a day/7 days a week.




Scan the QR code for essential information, guides (video and/or written), and tips to make the most out of your purchase.

FUNCTIONS



1. LED power indicator
2. Power button
3. Power input
4. Audio output
5. Audio input

SET-UP



From Microphone

WARNING: Before you disconnect or connect a mic to the PSP5, be sure to turn off the power. Failure to do so could result in severe damage to the microphone.

SPECIFICATIONS

- Power supply mode: DC 5V
- Input current: >200mA
- Working current: <100mA
- Output voltage: DC 48V
- Consumption power: $\leq 1W$
- Noise: <1 μV
- Input port: Balanced XLR
- Output port: Balanced XLR

RockvilleAudio.com

© 2026 ROCKVILLE // Features and specifications are subject to change and/or improvement without notice.