

# **RPB27 V2**

20W PORTABLE WATERPROOF SPEAKER W/WIRELESS STREAMING and TWS

# **OWNER'S MANUAL**

# ATTENTION: WATCH THIS VIDEO BEFORE FIRST USE!

## Who reads manuals?

Scan the **QR code** or go to **rockvillesupport.com/ rpb27-v2** to access how-to video(s), assembly video(s), the owner's manual, and other important information you may need to get the most out of your item.

If you prefer written instructions, please read ahead!

With Rockville you get many options.



**Missing items?** If you ordered a bundle that includes more than one product and you are missing part of your bundle then it just means your order shipped from two different warehouses. You will receive the remaining items very soon. If you have any concerns or inquiries, feel free to call our customer support center at 1-646-758-0144, 24 hours a day/7 days a week.

Thank you for purchasing this Rockville RPB27 V2 Rugged Water Resistant Portable Wireless Streaming Speaker.

The RPB27 V2 is a portable wireless streaming speaker that is the perfect size and power. This speaker is big enough that our engineers were able to get the speaker to produce 20 watts of power with huge bass! It is small enough to bring it with you camping, hiking, or anywhere else. The speaker is extremely rugged! It is shockproof and IPX6 water resistant. This means you can throw it around and bring it in the shower and the speaker will never break!

There may be some similar looking wireless streaming speakers on the market but this is the only speaker at this price point that is rugged, water resistant, and has huge power with huge bass!

Please read this guide carefully for proper use of your RPB27 V2. Should you need technical assistance please call our technical help line at 1-646-758-0144, 24 hours a day, 7 days a week.



 To reduce risk of electric shock, never open the unit. There are no user serviceable parts, refer service to the Rockville service center.

### Features and Specifications


- Deep bass in a compact size
- IPX6 Water Resistant
- 20 watts peak power/10 watts RMS
- 1200mAh battery w/9.5 hours playback at 50% volume/3.5 hours at max volume
- Wireless streaming w/40 foot long range
- TWS True Wireless Stereo Linking of 2 speakers
- Extremely loud, powerful, and rugged and shockproof
- Includes Aluminum hook to latch it onto a backpack, pocket book, etc
- The built-in mic allows you to make and receive phone calls hands-free
- Charge time: 1.5 2 Hours
- Rubberized impact-resistant silicone feet
- Playback Controls: Play, Pause, Skip Forward/Back, Volume Up/Down
- Battery charges with included USB cable
- Natural sound with enhanced bass response
- Frequency Response: 125Hz 18kHz
- Perfect for multiple applications such as camping, hiking, pool, beach, shower, bedroom, iPad/Laptop speaker, kitchen speaker, etc.
- Compatible with many wireless streaming devices such as iPads, iPhones, Laptops, Android phone, and other cell phones
- Dimensions of Unit (inches): 6.22" x 2.1" x 2.44"
- Unit weight: 0.77 lbs


#### Included

- RPB27 V2 Wireless Streaming Speaker
- Aluminum Carabiner Clip
- Lanyard
- Micro USB Charging Cable
- Owner's Manual
- Warranty card

#### **Functions**

- 1. Micro USB charging port
- 2. 3.5mm Aux input
- 3. LED indicator
- 4. Power On/Off
- 5. Next/Volume +
- 6. Play/Pause/Hands free calling
- 7. Previous/Volume -





# Wireless Streaming

- 1. Press and hold the power button for 2 seconds to enter wireless streaming mode; the LED indicator will be blue and blink rapidly.
- 2. Ensure your device is in "Bluetooth" mode and discoverable.
- 3. Under list of available devices search for RPB27 V2.
- 4. Select Rockville. If a pairing code is requested, please use "0000" or "1234".
- 5. LED indicator will be solid when the unit is successfully paired. Once playback begins, the LED will blink slowly.
- 6. Press and hold the Play button for 5 seconds to unpair from current device and re-enter paring mode.
- 7. Press the PLAY/PAUSE button to pause and resume playback. Press the -/+ buttons at the top of the unit to raise or lower the volume. At max volume, the unit will chime. Press and hold the -/+ buttons for 1 second to navigate through tracks.

#### **TWS**

- 1. Press and hold the POWER button on the first unit for 2 seconds to enter wireless streaming mode; the LED indicator will be blue and blink rapidly.
- 2. Ensure your device is in "Bluetooth" mode and discoverable.
- 3. Under list of available devices search for RPB27 V2.
- 4. Select Rockville. If a pairing code is requested, please use "0000" or "1234".

- 5. LED indicator will be solid when the unit is successfully paired. This will unit will act as the right channel.
- 6. Turn on the second unit, then double press the POWER button. You will hear a tone indicating the unit is attempting to pair to the first unit. Upon pairing, you will hear a second tone. This will be the left channel.
- 7. On either unit, press the PLAY/PAUSE button to pause and resume playback. Press the -/+ buttons at the top of the unit to raise or lower the volume. At max volume, the unit will chime. Press and hold the -/+ buttons for 1 second to navigate through tracks.

### Hands-Free Operation

- 1. To answer a call press the PLAY/PAUSE button.
- 2. Use the volume buttons to adjsut call volume.
- 3. Press the PLAY/PAUSE button to end a call.
- 4. Press PLAY/PAUSE button for 1 second to decline a call.

#### Aux Mode

- 1. Plug in a 3.5mm jack and the unit will automatically switch to AUX input.
- 2. Note, if you begin wireless streaming while in AUX mode, the unit will automatically switch to that mode. To return to AUX mode, unplug and plug the aux cable attached to the unit.
- 3. Volume can be controlled from the unit and the input the device. Playback is controlled from the input device only.

## Charging

- 1. To charge the RPB27 V2 plug the included micro USB cable into the port on the right side of the unit.
- 2. While charging the LED indicator will be red (when the unit is off). Once fully charged the LED indicator will turn off. Red charging LED may not go off if unit is on and playing audio
- 3. Charge time is 1.5 2 hours.

#### Power Save:

If the unit senses no signal for 3 minutes, it will automatically power down to conserve battery life. If the unit is in wireless streaming mode and paired, the unit will not turn off.

#### FEDERAL COMMUNICATIONS COMMISSION COMPLIANCE INFORMATION

Responsible party name: Rockville

Address: 600 Bayview Ave,

Entrance A,

Inwood, NY 11096

Hereby declares that the product Rockville RPB27 V2 rugged water resistant portable Bluetooth speaker complies with FCC rules as mentioned in the following paragraph:


This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



# ROCKVILLE



# RockvilleAudio.com