

ROCKVILLE

RKI65BT

DUAL UHF WIRELESS MICROPHONES
w/BLUETOOTH KARAOKE MIC INTERFACE

OWNER'S MANUAL

ATTENTION:
WATCH THIS VIDEO BEFORE FIRST USE!

Who reads manuals?

Scan the **QR code** or go to **rockvillesupport.com/rki65bt** to access how-to video(s), the owner's manual, and other important information you may need to get the most out of your item.

If you prefer written instructions, please read ahead!

With Rockville you get many options.



Missing items? If you ordered a bundle that includes more than one product and you are missing part of your bundle then it just means your order shipped from two different warehouses. You will receive the remaining items very soon. If you have any concerns or inquiries, feel free to call our customer support center at 1-646-758-0144, 24 hours a day/7 days a week.

רענארוק

Thank you for purchasing this Rockville RKI65BT Karaoke Interface. Please read this guide carefully for proper use of your RKI65BT. Should you need assistance, please call our technical help line at 1-646-758-0144, 24 hours a day/7 days a week.

INCLUDES


- Mic receiver/mixer
- (2) UHF wireless microphones
- Power adapter
- (1) 3.5mm to 3.5mm AUX cable, 5 ft
- (1) 3.5mm to RCA cable, 5 ft
- (1) ¼" TS to ¼" TS cable, 3.2 ft
- (1) optical cable, 5 ft
- Manual

IMPORTANT SAFETY INSTRUCTIONS




- To reduce risk of electric shock, never open the unit. There are no serviceable parts. Refer service to the Rockville service center.
- Do not expose this unit water.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other devices that produce heat.
- Do not defy the safety purpose of the polarized grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or third prong is provided for your safety. If the provided prong does not fit your outlet, consult an electrician for possible replacement of an obsolete outlet.
- Protect the power cord from being walked on or pinched, particularly at plugs, receptacles and/or the point where they exit from the device.
- Only use attachments/accessories specified or included with this unit.
- Unplug this device during lightning storms or when not in use for prolonged periods.

FUNCTIONS




- 1. Antenna
- 2. Power LED Indicator
- 3. Power button
- 4. Echo knob: sets the number of repetitions of the echo effect.
- 5. Tone knob: adjusts the high frequency levels.
- 6. Mic A RF indicator LED: will light when Mic A is connected.
- 7. Mic A knob: sets the volume level for Mic A
- 8. Mic B RF indicator LED: will light when Mic B is connected.
- 9. Mic B knob: sets the volume level for Mic B.
- 10. Music knob: sets the volume level for any audio source connected to any of the inputs on the rear panel.



- 12. 3.5mm and 1/4" outputs: output a mix of the audio source and the mic signal.
- 13. Optical input: carries a digital audio stream from components such as TVs, CD players, DVD players, and computers.
- 14. Coaxial input
- 15. 3.5mm AUX input
- 16. DC Power in 5V/1A

FUNCTIONS




1. Windscreen
2. Battery status indicator
3. Signal strength
4. Frequency
5. Mic channel
6. Power button/frequency adjustment button
7. Battery compartment (uses 2x AA alkaline batteries)
8. Antenna

OPERATION

1. Connect the receiver to a power outlet and turn it on.
2. Put two AA alkaline batteries into the battery compartment of the microphone. Please make sure to observe proper polarity.
3. Power on the microphone(s). In case of any frequency interference, quickly press the power button on the microphone to change the frequency. There are up to 8 frequencies available. Please note that it will take a few seconds for the receiver to automatically sync with the mic whenever the mic frequency is changed.
4. When first used, the receiver and mics are not matched. The receiver and mics can be used interchangeably, but if more than 1 set of mics and receivers is being used, each set of mics must be specifically matched to the corresponding receiver. Otherwise, you cannot use more than one set in a location.


Please note: If there is no sound input to the mics for more than 5 minutes, they will automatically shut down in order to conserve battery life.

Matching the Receiver and Mics


1. Connect the receiver to a power outlet and turn it off
2. Turn the mic off. Hold the power button until the numbers flash. Press the power button again. The  icon should also begin to flash.
3. Quickly turn on the receiver (within 2 seconds). The RF A LED will light. That mic is now matched to channel A. Repeat these steps for the other microphone.

Please note: Even though the mics are matched to a specific channel, you cannot use the same frequency on both mics.

Tip: To minimize feedback avoid operating the microphones in close proximity of or in front of speakers.




COMPUTER CONNECTION



PLEASE NOTE: Some computers feature Bluetooth connectivity. If your computer is Bluetooth capable, please see the pairing instructions on page 7.


DVD PLAYER, BLU-RAY PLAYER, TV CONNECTION



PLEASE NOTE: OPTICAL IN port does not support TV PCM Dolby 5.1 output.
Some TVs and receivers feature Bluetooth connectivity. If your device is Bluetooth capable, please see the pairing instructions on page 7.

MOBILE DEVICE CONNECTION


The RKI65BT features mobile device connection via Bluetooth or a 3.5mm AUX input.





BLUETOOTH CONNECTION

1. Power on the RKI65BT. It will automatically enter into pairing mode.
2. Ensure that your device is in Bluetooth mode and discoverable.
3. Find "RKI65BT" on your device's list of available Bluetooth connections and select it.
4. If pairing is successful, you will hear audio through the connected speakers.
5. Playback is controlled by your Bluetooth device.




OR



SPEAKER CONFIGURATIONS



Powered Speakers



Passive Speakers

FEATURES

- Bluetooth input
- 3.5mm aux input
- Optical input
- Coaxial input
- 1/4" TS mix output passes through the signal of all the mics, as well as any input device
- 3.5MM aux output passes through the signal of all the mics, as well as any input device
- 2 UHF wireless microphones with 8 switchable frequencies
- Each mic has a nice heavy feel and features a digital display making it easy to switch frequencies
- Adjustable echo
- Adjustable tone control
- Adjustable music input volume
- Independently adjustable mic levels
- Wireless frequency range:
Mic A: 556.1, 558.4, 560.7, 562.2, 564.5, 566.8, 568.3, 570.6
Mic B: 574.1, 576.4, 578.7, 580.2, 582.5, 584.8, 586.3, 588.6
- Number of channels: 8
- THD: 0.5%
- Signal/Noise ratio: 90dB
- Frequency response : 30Hz – 18kHz \pm 3dB
- Operating range: 200 Feet
- Transmitting power: 10dBm
- Power supply: 3V (2 AA Batteries)
- 100-240V compatible with included micro USB power cable (5 feet)

TROUBLESHOOTING

No power	<ol style="list-style-type: none">1. Make sure the power is on.2. Check for loose or disconnected power adapter or cable.
Unit has power, but no sound	<ol style="list-style-type: none">1. Check unit volume settings (Mic A, Mic B, Music)2. Check source device volume and disable any mute settings.3. Make sure your speakers are properly connected.
Mics not working	<ol style="list-style-type: none">1. Check the batteries.2. Make sure the mics are powered on.3. Make sure the mics are paired.4. Check the mic frequency,
Bluetooth pairing fails	<ol style="list-style-type: none">1. Check to see that both devices are turned on and that your Bluetooth device is discoverable.2. Turn both devices off and then on again.3. Make sure that the Bluetooth device is within 5 feet of the unit.4. Move both devices away from other Bluetooth devices, microwaves, wireless routers, etc.5. Make sure that all volume controls are set properly.
Sound is poor or distorted	<ol style="list-style-type: none">1. Reduce source volume.2. Change placement angle between mic and speaker.3. Change distance between mic and speaker.

FEDERAL COMMUNICATIONS COMMISSION COMPLIANCE INFORMATION

Responsible party name: Rockville

Address: 600 Bayview Ave,
Entrance A,
Inwood, NY 11096

Hereby declares that the product RKI65BT complies with FCC rules as mentioned in the following paragraph:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

רועה נאמן

Visit us at:

RockvilleAudio.com

©2024 ROCKVILLE // The information presented is subject to change and/or improvement without notice.